



Electrolux

Factory Parts Catalog

Product No.	E30IC75FSS1
	38066224760S1
Series	30" elec
Color	stainless
Market	North America
Wiring Diagram	318046815
Owner's Guide	318200630
Installation Instructions	318201430
Service Data Sheet	318200251

Electrolux

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917

Publication No.
5995470167
06/07/18
(EN/SERVICE/ECL)
377

ELECTRIC COOK-TOP RANGE

Model No.
E30IC75F

Copyright © 2006 Electrolux Home Products, Inc.
All rights reserved.

CONTROL



CONTROL PANEL

POS. NO	PART NO.	DESCRIPTION
1	318348100	Housing, plastic carrier
2	318347100	Generator, circuit board, (2)
4	318347000	Filter, circuit board
5	318346900	Cooling Fan Assembly
6	318348001	Communication Cable, generator, 18", to filter
7	318348000	Communication Cable, generator, 6", to filter
8	318052581	Power Cable Set, generator, 18", black, to filter
9	318052580	Power Cable Set, generator, 6", blue, to filter
10	318052582	Power Cable Set, generator, 18", blue, to filter
11	318052579	Power Cable Set, generator, 6", black, to filter
12	318052578	Ground Wire
20 #	318330811	Touch Control, electronic, main
20A#	318330711	Touch Control, cook zone, (2), electronic
21	318083044	Interface Cable, zone, main, (2)
22	318083045	Communication Cable, control, main, to filter
23	318368900	Frame, display, (4)
23A	318368910	Frame, display
24	318349900	Thermistor
*	5304457268	Washer, flat, nylon, (4)
*	5304457269	Palnut, #8-32, (6)
*	5304457271	Tape, foam, 1/4"x1"x1", (6)



MAIN TOP/SURFACE UNITS

POS. NO	PART NO.	DESCRIPTION
1	318329004	Panel, CARRIER
*	08016432	Screw, truss head, 8-18 x 0.375
2	318344500	Insulation, elements
10	5304450850	Screw, 7-19 x 1/2", (11), housing ring
15 #	318329200	Element, induction coil, 145MM, right rear
15A#	318329201	Element, induction coil, 180MM, left rear
15B#	318329202	Element, induction coil, 210MM, left front
15C#	318329203	Element, induction coil, 260MM, right front
16	318282519	Main Top Assy, glass/steel, black/stainless
20	318121906	Bracket, retainer
34	318526700	Pan, skillet, induction
46	318328917	Box, burner
47	318345113	Deflector, air
50	318356803	Panel, spacer
57	318330911	Panel, access
58	318346000	Insulation, housing, RH
58A	318346002	Insulation, housing, rear
58B	318346001	Insulation, housing, LH
59	318346201	Insualtion, housing, lower
60	318346101	Deflector, air
61	5304424462	Foam Tape, 1/2" x 14"
163	318014110	Spacer, (6)
* #	318078552	Box & wires assy
*	318341500	Clamp, power cord
*	5303323140	Screw, ground, 10-32 x 0.375
*	316459400	Pad, cleaning
*	5303307980	Screw, 8-32 x 0.437, (4)

WIRING DIAGRAM

